Moov V Series

User Manual

Important Safety Information

PLEASE READ CAREFULLY BEFORE INSTALLING PRODUCT IN VEHICLE

⚠	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
⚠WARNING	WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
⚠CAUTION	CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
CAUTION	CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

⚠WARNING

Removing original equipment, adding accessories or modifying your vehicle could affect the vehicle's safety or make it illegal to operate in some jurisdictions.

Follow all product instructions and all instructions in your vehicle owner's manual regarding accessories or modifications.

Consult your country's and/or state's laws regarding operation of a vehicle with any accessories or modifications.

It is your sole responsibility to place, secure and use your Mio in a manner that will not cause accidents, personal injury or property damage. Always observe safe driving practices.

Do not mount your Mio or attach the antenna in a way that may interfere with the safe operation of the vehicle, the deployment of air bags or other safety equipment.

Do not operate your Mio while driving.

Before you use your Mio for the first time, familiarise yourself with your device and its operation.

On main roads, the distance to an exit calculated by your Mio may be further than the distance shown on road signs. Road signs show the distance to the start of an exit while your Mio shows the distance to the next intersection, i.e., the end of the exit ramp or road. To prepare to exit a road, always follow distance information on road signs.

The use of information regarding safety or speed camera locations may be subject to local laws in the country of use. You are responsible for checking that you can legally use the information in your country or in the country where the information will be used.

Products with FM Transmitter feature may be operated in the following countries: Andorra, Austria, Belgium, Denmark, Finland, Germany, Ireland, Liechtenstein, Luxembourg, Monaco, Netherlands, Norway, Portugal, San Marino, Spain, Sweden, Switzerland, Great Britain and Vatican City. The FM Transmitter is not allowed to be used by law in France, Andorra, San Marino, and Vatican City. Please turn of the FM Transmitter in those areas.

The TV, video player and AV input features MUST NOT be used when driving. Using this feature may cause an accident. Please make sure you comply with this warning. Mio accepts NO liability whatsoever in this regard.

⚠CAUTION

Do not handle your Mio while it is hot. Let the product cool, out of direct sunlight.

At full power, prolonged listening to your Mio via headphones or earphones can damage the ear of the user.

CAUTION

Do not expose your Mio to direct sunlight in an unattended vehicle for prolonged periods. Overheating may damage the unit.

To discourage theft, do not leave your Mio, mounting bracket or any cables in plain view in an unattended vehicle.

Warning Notice to Drivers in the United States

State law may prohibit drivers in states such as Arizona, California and Minnesota from mounting objects on their windscreens while driving. Please make sure you research and follow your most current State laws. An alternative mounting option may be provided in the box with your product; or see mio.com for additional mounting alternatives. Mio does not take any responsibility for any fines, penalties, or damages that may be incurred as a result of disregarding this notice.

Failure to adhere to these warnings and cautions may lead to death, serious injury or property damage. Mio disclaims all liability for installation or use of your Mio that causes or contributes to death, injury or property damage or that violates any law.

Contents

Important Safety Information 2

Welcome 5

How do I use the touch screen? 6

How do I get started? 7

Main Menu 8

How do I go from A-B? 9

- What if I miss a turn? 9
- Using the Keyboard screen 9
  - How can I set my keyboard preference? 10
  - How does predictive text (abc, def…) work? 10
- How do I plan my first trip? 11
- How do I set my route preferences? 12
- How do I search for a Point of Interest (POI)? 13
- How do I view my route? 15
- How do I use the Explore map? 16
  - How do I find a POI using the POI Cluster? 16
  - How do I find a POI on my route? 17
- How do I set my POI preferences? 18

How do I preview a route? 19

How do I view my route statistics? 20

How do I navigate to a recent place? 21

How do I find the nearest POIs? 22

My Places 23

- How do I save a location as My Place or Home? 23
- How do I navigate to a location I have saved? 24
- How do I navigate to Home? 24
- How do I edit the name of a location in My Places? 25
- How do I delete a saved location? 25
- How do I navigate to a **NavPix**™? 25
  - How do I navigate to a **NavPix**™ in an album? 26
  - How do I view a **NavPix**™ in full-screen? 27
  - How do I save a **NavPix**™ as a favourite? 28
  - How do I add or edit a **NavPix**™ title? 28
  - How do I delete **NavPix**™ from an Album? 28

How do I capture a location or a journey? 29

- How do I capture the GPS co-ordinates of my location? 29
- How do I capture a location with a voice recording? 29
- How do I capture a journey? 30
- How do I navigate to a location I have captured? 30
- How to view a journey I have captured? 30
- How to share a journey I have captured? 30

How do I create a trip with multiple stops? 31

- How do I delete a waypoint from my trip? 33
- How do I change the order of the waypoints? 33
- How do I edit a planned trip title? 34
- How do I skip a waypoint during a multi-stop trip? 34

What is Travel Book? 35

- How do I search for a POI in a city I am visiting using Travel Book? 35
  - How do I add / remove city guides on my Mio? 36

How do I watch digital TV? 37

- Watching TV programs 37

Changing TV settings 38
How do I play media? 39
Playing audio files 39
How do I listen to a music file on my Mio? 39
Playing video files 40
How do I view a video file on my Mio? 40
How do I view a video file on full screen? 41
How do I receive audio through my vehicle speakers? 43
How do I set the audio output channel of my Mio through my car's FM radio? 43
How do I receive current traffic information via TMC? 44
How will I know when a Traffic Event occurs? 44
Traffic Overview screen 45
How do I view a list of all events on my route? 45
How do I view traffic details? 46
How do I know if a detour is recommended? 47
How do I avoid an event on my route? 47
How do I cancel a detour around an event on my route? 48
Traffic messages 48
Traffic preferences 49
TMC service 49
Traffic Event Notification 49
Select event sorting type 49
Walking mode 51
How can I set my navigation mode to walking? 51
What can I customise? 52
Volume 52
Safety options 52
Route options 53
Map display 54
Screen brightness 54
Language 55
Voice 55
Power management 55
Units 56
Touch audio 56
List scrolling 57
Audio output 57
Delete saved information 57
Reset GPS 58
Restore factory defaults 58
Shop demo 58
Screen saver 59
About 59
Point of Interest categories 60
Traffic and other TMC Events 63
Appendices 64
For more information 64
Speed Limit 64
Safety Camera POIs 64
FM Transmitter 64
Disclaimer 64
Copyright 65

Welcome

Thank you for purchasing this Mio. This manual has been prepared to guide you through the operation of your Mio from first set-up through to continuous use. Please read this manual carefully before using your Mio for the first time. Keep this manual in a safe place and use as your first point of reference.

Important information for using the manual

It is important to understand the terms and typographical conventions used in this manual.

Formatting

The following kinds of formatting in the text identify special information:

Convention	Type of Information
Bold	Mio components or items displayed on screen, including buttons, headings, field names and options.
Italics	Indicates the name of a screen.

Icons

The following icons are used throughout this manual:

Icon	Description
	Note
	Tip
	Warning

Terms

The following terms are used throughout this manual to describe user actions.

Term	Description
Tap	Press and release an item displayed on the touch screen.
Tap and hold	Tap and hold an item displayed on the touch screen for 2-3 seconds.
Select	Tap an item in a list or tap a command from a menu.
Drag	Hold your fingertip on the screen and drag up/down/left/right or across the screen.

How do I use the touch screen?

By default, your Mio starts in button mode, to scroll up or down, or dock/undock use the buttons to the right of the main page.





You can change to Slide Touch™ mode: tap **MY MIO → List Scrolling**.

In Slide Touch™ mode, your Mio touch screen options change dynamically:

- To see all options on a menu, drag the screen up or down.
- To display the next screen, tap an icon or select an option.
- To dock a menu to the left, tap the left edge of the menu. To dock a menu to the right, tap the right edge of the menu.



Main Menu options and the order of the options may differ from the above, depending on your region, maps installed or model of Mio.

How do I get started?

The first time you use your Mio it may take several minutes to establish a GPS connection.

How do I turn my Mio on for the first time?

To get started for the first time, complete the following steps:

1. **Read the Important Safety Information** (see "Important Safety Information" on page 2).

2. **Position your Mio in your vehicle.**
   Follow the instructions in the *Hardware User Manual*.

   CAUTION Ensure that your Mio does not obstruct the driver's view, or interfere with the operation of the vehicle airbags and safety devices.

3. **Turn your Mio on**

   Your Mio will turn on and display the *Language* screen.

4. **Select your preferred language**

   From the *Select Language* screen, tap your preferred language.

- You can change your preferred language while using your Mio, see "Language" on page 55.

5. **Read the warning message**

   a) The *Safety Agreement* screen will display after you have selected your preferred language.
   Read the Safety Agreement message.

   b) To confirm that you have read and understood the message, tap **Accept**.
   The *Tutorial* will display.

6. **View the Tutorial**

- To skip the Tutorial screens, tap **Skip**.
- To move forward through the Tutorial screens, tap Next.

  To view the previous screen, tap .

To prevent the *Tutorial* from displaying on each start-up, tap the **Show on start-up** option to deselect it.

When you have finished the *Tutorial*, the *Map* screen will display. If you have a GPS fix, your current location will display on the map.

Main Menu

The *Main Menu* is your starting point for searching for a destination. The *Main Menu* also allows you to customise your Mio, receive updated traffic information (not available on all models) and make and receive phone calls (not available on all models).

- To display the *Main Menu*, press on your Mio at any time.







	Search for places, areas and streets to help plan your route.		Access your saved locations, NavPix™, journeys, etc.
	Explore the area around your current position or destination.		Search for information and POIs for the city you are visiting using Travel Book.
	Display the map screen.		Record GPS co-ordinates of a location or a journey.
	Allows you to watch digital TV (if an optional digital TV card is installed on your Mio).		Configure your Mio to enhance your navigation experience.
	Search for the nearest petrol stations.		Add or begin a planned trip with multiple waypoints
	Set or navigate to your home address.		Receive live traffic information on your route and set traffic preferences. (may require optional TMC kit or subscription, available separately)
	Play stored audio or video files installed on your Mio or on a memory card.		Search for the nearest emergency services, including hospitals and police.
	Search for the nearest restaurants, cafes, fast-food premises and other dining establishments.		Search for the nearest tourist attractions.
	Search for the nearest parking places.		Search for the nearest banks and ATMs.

Main Menu options and the order of the options may differ from the above, depending on your region, maps installed or model of Mio.

How do I go from A-B?

Your Mio is equipped with maps that provide street-level detail for door-to-door navigation, including Points of Interest such as accommodation, parking areas, petrol stations, railway stations and airports.

When you ...	Then ...
need to search for an address	tap **FIND** then **Find a street address** to search for the address. If you know the address you are looking for, use the Map screen to enter an address
need to find a named site, feature, landmark or public venue	tap **FIND** then **Find by keyword** to search for a Point of Interest.
want to navigate to a recently visited location	tap **MY PLACES** then **Recent places**.

WARNING For your safety, enter destination information before you start a journey. Do not enter a destination while driving.

What if I miss a turn?

Back-On-Track™ Automatic Rerouting

You will be redirected if you make a wrong turn. A message informing you that your route is being re-calculated will display at the top of the screen.

To cancel a route re-calculation, tap **x**. A warning will display asking you to confirm the cancellation. If confirmed, both the re-calculation and your current route will be cancelled.

Using the Keyboard screen

The *Keyboard* screen will display when you are required to enter text, such as when searching for a street name. Search results will be listed in matching order, with the closest matches appearing on the screen. A maximum of 99 results will display.

The *Keyboard* screen can display with various layouts depending on the information you need to enter, including alphabet, number, alternate characters and combinations of these.

- To select a character, tap the character.
  To enter upper case letters, tap ↑.
- To delete a character, tap DEL.
  Tap and hold DEL to delete the entire text.
- To display more characters, tap .;/+ to select an alternate keyboard screen.

How can I set my keyboard preference?

From the *Keyboard* screen, tap .;/+.
The *Keyboard* preference screen will display.



How does predictive text (abc, def…) work?

Predictive text allows addresses to be searched by a single key-press for each letter, as opposed to the multiple key-presses. As you enter a letter of an address, your Mio will compare all possible combinations against the maps you have installed and determine which address you intended to type.

For example:

To enter **London**, tap **JKL** **MNO** **MNO** **DEF**.

Your Mio will compare all possible combinations and display **London** in the list of search results. You can add further letters to narrow the search.

How do I plan my first trip?

Using your Mio to plan your first trip is easy. There are several ways to select your destination. Complete the following to navigate to a street address that you know using the **FIND** address wizard.







Complete the following:

If you want to ...	Then ...
calculate the route, open the *Map* screen and start navigating	▪ tap . The *Map* screen will display.
save the location as Home	▪ tap . The *Save* screen will display. ▪ tap **Save as Home**.
save the location as a favourite	▪ tap . The *Save* screen will display. ▪ tap **Save as My Place**.
explore the area near the location	▪ tap . The *Explore Map* screen will display. ▪ tap the undock button or tap the docked menu in Slide Touch™ mode to see the menu options. ▪ complete one of the following: o tap **Streets** to explore streets near your location o tap **Areas** to explore areas around your location o tap a POI category to explore POIs near your location

How do I set my route preferences?

You can enhance your navigation experience by modifying aspects of your route and route calculations.

1. From the *MAP* screen, tap the undock button and tap *Route options*.
   The *Route options* screen will display.

   OR

   → → **Route options**.
   The *Route options* screen will display.

2. Complete the following:

If you want to ...	Then ...
set route type options for your route	▪ tap **Route type**. The *Route type* screen will display. ▪ select your route type preference form the list. **Shortest** - The route with the shortest physical length **Easiest** - The simplest route with the least number of turns and favours motorways where appropriate **Economical** - The route with least number of stops, turns and urban areas which should save on fuel usage **Fastest** - The route that should be the fastest when navigating Selecting **Shortest** route type over **Fastest** route type can cause a much longer journey time.
set types of road options for your route	▪ tap **Types of road**. The *Types of road* screen will display. ▪ select your road preference form the list. Avoiding ferry routes may prevent you from navigating between certain countries, even when a bridge or tunnel exists.
set your map screen preference	tap the **Map** option to select between a 3D or 2D view of the *Map* screen.
Set the number of turns displayed on your turn list	▪ tap **Displayed turns**. The *Displayed turns* screen will display. ▪ select your turn preference form the list.
display Junction views on your route	tap the **Junction views** option to turn it **On** or **Off**.
set how you want to receive the safety camera alerts	▪ tap **My Places alerts**. The *My Places alerts* screen will display. ▪ select a safety camera category from the list and select the desired setting.
record mileage for your route to generate expense reports	tap the **Mileage recorder** option to turn it **On** or **Off**.

If you want to ...	Then ...
record a GPS log of your trip	tap the **GPS logging** option to turn it **On** or **Off**.
record your journey	tap the **Capture Journey** option to turn it **On** or **Off**.

How do I search for a Point of Interest (POI)?

A POI is a named site, feature, landmark or public venue which can be displayed as an icon on the map. POIs are grouped by category, such as petrol stations, parks, beaches and museums.





Complete the following:

If you want to ...	Then ...
calculate the route, open the *Map* screen and start navigating	▪ tap . The *Map* screen will display.
save the location as a favourite	▪ tap . The *Save* screen will display. ▪ tap **Save as My Place**.
place a phone call to the POI	▪ tap . This feature is not available on all models.

If you want to ...	Then ...
explore the area near the location	▪ tap . The *Explore Map* screen will display. ▪ tap the undock button or tap the docked menu in Slide Touch™ mode to see the menu options. ▪ complete one of the following: o tap **Streets** to explore streets near your location o tap **Areas** to explore areas around your location o tap a POI category to explore POIs near your location

How do I view my route?

When a route has been calculated, the *Map* screen will display. You will be directed to your destination by spoken and visual instructions. Tap anywhere on the Map screen to show all options.



	Item	Description
❶	**Direction and distance of next turn**	The direction and distance to your next turn. ▪ Tap to repeat the vocal instruction.
❷	**Current route**	Your current route is highlighted.
❸	**Current position**	▪ In **Driving** mode, your current position is marked with . ▪ In **Walking** mode, your current position is marked with .
❹	**Add waypoint to trip**	Adds a location as a waypoint on your trip. ▪ Tap to remove the waypoint from your trip.
❺	**Detour**	Detours your route to avoid next 1, 2, 5, 10 or 20 miles.
❻	**Pause route**	Pauses your current route. ▪ Tap to unpause your current route.
❼	**Cancel route**	Cancels your current route.
❽	**Volume**	Mutes or unmutes the volume.
❾	**Distance and Time Information**	Tap to expand and select the following options: ▪ DTG (Distance to Go) ▪ TTG (Time to Go) ▪ km/h or mph (speed) and compass heading ▪ ETA (Estimated Time of Arrival) ▪ Time
❿	**Zoom**	▪ To zoom out, tap and hold **−**. ▪ To zoom in, tap and hold **+**.

How do I use the Explore map?

The *Explore* map allows you to explore the local area to find Points of Interest (POIs) or navigate to an address. If you do not have a GPS fix, the map will display your last known position.

- Tap and drag the map to explore your desired local area.
- Tap the map to display a POI Cluster showing POIs in the surrounding area. Tap a POI icon to show more information and navigate to the POI.



	Item	Description
❶	**+, −**	To zoom in or out, tap and hold **−** or **+**. Zooming in or out will increase or decrease the area contained within the Explore area.
❷		Indicates the direction of your current position. Tap to return the map to your current position.
❸	**POI Cluster**	To display a POI Cluster, tap an area on the *Explore* map. ▪ Tap an icon or street name in the POI Cluster to view information and options.
		increases or decreases the number of POIs displayed on your map, which will effect the number of results returned. Only visible POIs will be displayed in the POI cluster.*

* Zooming out too far will reduce the number of POIs displayed to zero and hence return no results.

How do I find a POI using the POI Cluster?



Tapping on the POI selected (in red square) will bring up the *Explore menu* with the POI destination details.

Complete the following:

If you want to ...	Then ...
calculate the route, open the *Map* screen and start navigating	▪ tap . The *Map* screen will display.
save the location as a favourite	▪ tap . The *Save* screen will display. ▪ tap **Save as My Place**.
place a phone call to the POI	▪ tap . This feature is not available on all models.

How do I find a POI on my route?



Complete the following:

If you want to ...	Then ...
calculate a new route, open the *Map* screen and start navigating	▪ tap . The *Map* screen will display.
add the location as a waypoint	▪ tap **Add as waypoint**. The Map screen will display and your route will be recalculated.
save the location as a favourite	▪ tap . The *Save* screen will display. ▪ tap **Save as My Place**.
place a phone call to the POI	▪ tap . This feature is not available on all models.

How do I set my POI preferences?

Points of Interest (POIs) are grouped into categories. You may choose to either display (or hide) icons of all POI categories on the map screens, or only display the icons from selected categories.

For example, you may only be interested in entertainment venues and want to disable other categories such as schools.

1. From the *Explore* screen, tap the undock button or tap the docked menu in Slide Touch™ mode and tap **Places settings**.
   The *Places settings* screen will display.



2. Complete the following:

If you want to ...	Then ...
display all POI icons (i.e. icons from all categories)	tap **Show all**.
display no POI icons	tap **Hide all**. Hiding POIs will stop you from finding them when using explore mode/cluster search.
select a specific POI category icon for display on the map screen	▪ tap the required POI category to **Show** or **Hide** on the map screen. ▪ Repeat until all required categories are selected.

- Your preferences are automatically saved.

How do I preview a route?

Route demonstration allows you to:

- Preview a route.
- Plan and view a route without a GPS fix, such as when you are inside a building.

The following steps will show you how to preview a route.

1. Select a departure point.

   If you have a GPS fix, you do not need to select a departure point unless you want the demonstrated route to start elsewhere.

   a) →
   The *Find* screen will display.

   b) Tap the undock button or tap the docked menu in Slide Touch™ mode to undock the menu screen.

   c) Scroll down and tap **Leaving from**.
   The *Leaving from…* screen will display.

   d) Tap **Find a place**, then use the Address Wizard to find your departure point.

2. Select a destination point using the **FIND** address wizard, the My Places menu or the *Explore* map.

3. From the *Preview* screen, tap .
   Your route is calculated and the *Map* screen will display.

4. Tap the undock button or the edge of the docked menu.
   The *GO* screen will display.

5. Tap **Route simulation**.
   The *Map* screen will display the calculated route in route simulation mode.

6. Complete the following:

If you want to ...	Then ...
increase the speed of the simulation	tap .
decrease the speed of the simulation	tap .
pause the simulation	tap .
cancel the simulation	tap .

How do I view my route statistics?

Your Mio provides information on your:

- distance to go
- estimated time of arrival
- distance travelled
- average speed
- maximum speed
- time taken for trip
- stationary time.

To view your route statistics during a planned route:

1. →
   The *Map* screen will display.
2. Tap the undock button or tap the docked menu in Slide Touch™ mode to undock the menu screen.
3. Tap.
   The *Route Statistics* screen will display.



How do I navigate to a recent place?

To make navigating to an address easier, your Mio will automatically save all your start locations and destinations in a list of recent places.

4. →

   The *My Places* screen will display.

5. Tap the undock button or tap the docked menu in Slide Touch™ mode to undock the menu screen.

6. Tap **Recent places**.
   The *Recent Places* screen will display.



7. Tap a recent place.
   The *Preview* screen will display.

8. Complete the following:

If you want to ...	Then ...
calculate the route, open the *Map* screen and start navigating	▪ tap . The *Map* screen will display.
save the location as a favourite	▪ tap . The *Save* screen will display. ▪ tap **Save as My Place** or tap **Save as Home**.
explore the area near the location	▪ tap . The *Explore Map* screen will display. ▪ tap the undock button or tap the docked menu in Slide Touch™ mode to see the menu options. ▪ complete one of the following: o tap **Streets** to explore streets near your location o tap **Areas** to explore areas around your location o tap a POI category to explore POIs near your location
save it as a waypoint in your current route	▪ → ▪ tap **Recent places**. ▪ select a location from the list. ▪ tap **Add as waypoint**.

How do I find the nearest POIs?

1. Complete the following:

If you want to ...	Then ...
search for the nearest petrol stations	→
search for the nearest emergency services	→
search for the nearest restaurants	→
search for the nearest tourist attractions	→
search for the nearest parking places	→
search for the nearest banks and ATMs	→

2. A list of the selected POI category based upon your current location is displayed.

3. Tap the desired item from the list, then tap on the Preview screen.

If you have a route planned, two distances will display: distance from your current location and detour distance.



My Places

My Places has all your saved and captured locations. It also contains POIs, NavPix™ and albums you have downloaded onto your Mio via MioMore Desktop.

How do I save a location as My Place or Home?

1. Search for an address until the *Preview* screen is displayed.



2. Tap **Add to My Places**.
   The *Save* screen will display.



3. Tap **Save as My Place**.
   The *Preview* screen will display.



4. Complete the following:

If you want to ...	Then ...
calculate the route, open the *Map* screen and start navigating	▪ tap . The *Map* screen will display.

If you want to ...	Then ...
explore the area near the location	▪ tap . The *Explore Map* screen will display. ▪ tap the undock button or tap the docked menu in Slide Touch™ mode to see the menu options. ▪ complete one of the following: o tap **Streets** to explore streets near your location o tap **Areas** to explore areas around your location o tap a POI category to explore POIs near your location
add or edit location name	▪ tap **Rename**. The *Keyboard* screen will display. ▪ after you have entered a name for the favourite, tap **OK**. The *My Places* preview screen will display.
delete the favourite location	▪ tap .

How do I navigate to a location I have saved?

1. →
   The *My Places* screen will display.
2. Tap the favourite destination you want to travel to.
   The *Preview* screen will display.



3. Tap .
   Your Mio will calculate the route from your current location. The *Map* screen will display.

How do I navigate to Home?

If you have not set an address as Home, the first time you try to navigate to Home you will be prompted to search for an address using the address-entry wizard.

1. →
   The *My Places* screen will display.
2. Tap **Home**.
   The *Preview* screen will display.



3. Tap .
Your Mio will calculate the route from your current location. The *Map* screen will display.

How do I edit the name of a location in My Places?

1. →
The *My Places* screen will display.

2. Select a location to edit.
The *Preview* screen will display.

3. Tap **Rename**.
The *Keyboard* screen will display.

4. After you have edited the name, tap **OK**.
The *Preview* screen will display.

How do I delete a saved location?

1. →
The *My Places* screen will display.

2. Select the location you would like to delete.
The *Preview* screen will display.

3. Tap **Delete**.
The location is deleted. The *My Places* screen will display.

How do I navigate to a NavPix™?

NavPix™ is an image or picture, normally of a location, which contains embedded GPS co-ordinates that you can navigate to.

Sample **NavPix**™ images may be pre-installed on your Mio. You can search online and download **NavPix**™ images from the Flickr™ or **NavPix**™ website.

To navigate to a **NavPix**™ location, either a GPS fix must have been available when the **NavPix**™ was taken, or GPS co-ordinates have been added using MioMore Desktop. See the *MioMore Desktop Manual* for more information on importing **NavPix**™ to your Mio.

1. →
The *My Places* screen will display.

2. Tap the **NavPix**™ you want to navigate to.
The *NavPix Details* screen will display.

3. Complete the following:

If you want to ...	Then ...
calculate the route, open the *Map* screen and start navigating	▪ tap . The *Map* screen will display.
view **NavPix**™ location on the map	▪ tap **Show on map**. The *Explore Map* screen will display.
explore the area near the **NavPix**™ location	▪ tap . The *Explore Map* screen will display. ▪ tap the undock button or tap the docked menu in Slide Touch™ mode to see the menu options. ▪ tap on the map to explore POIs near the location.
edit **NavPix**™ name	▪ tap **Rename**. The *Keyboard* screen will display. ▪ after you have entered a name for the favourite, tap **OK**. The *NavPix Details* screen will display.
delete the **NavPix**™ from My Places	▪ tap . The *My Places* screen will display.

NavPix™ can be deleted from an Album on your Mio internal memory or your memory card. When a **NavPix**™ has been saved as a Favourite destination, you will not delete the Favourite if you subsequently remove the **NavPix**™.

How do I navigate to a NavPix™ in an album?

The albums contain all your pictures and displays them as thumbnails.

→ →



	Item	Description
❶	**Slide Show**	Displays all images in the album as a full-screen slideshow.
❷	**Album title**	The title of the album.
❸		Indicates that the picture is a **NavPix**™, with embedded GPS co-ordinates.
❹	**NavPix**™ **thumbnail**	A thumbnail of a **NavPix**™ contained in the album. ▪ To select a **NavPix**™, tap the thumbnail. The *NavPix Details* screen will display.

How do I view a NavPix™ in full-screen?

1. From the *NavPix Details* screen, tap the thumbnail of the **NavPix**™.
   The **NavPix**™ will appear in full-screen.

   OR

   From the *Album detail* screen, tap **Slide Show**.
   The **NavPix**™ will appear in full-screen

2. Tap the screen to display the control buttons. The buttons disappear after a few seconds.

3. Complete the following:

If you want to ...	Then ...
zoom into the **NavPix**™	tap .
zoom out of the **NavPix**™	tap .
rotate the **NavPix**™	tap . The **NavPix**™ will rotate 90 degrees anticlockwise each time is tapped; the **NavPix**™ is saved at the new angle.
view parts of the **NavPix**™ not displayed on-screen	tap and hold the **NavPix**™, then drag across the screen.
return to the *NavPix Details* screen	tap .

How do I save a NavPix™ as a favourite?

You cannot save a **NavPix™** as a favourite if GPS co-ordinates are not available.

1. From the *Album* screen, tap a **NavPix™**.
   The *NavPix Details* screen will display.
2. Tap .
   The *Save* screen will display.
3. Complete the following:

If you want to ...	Then ...
save the **NavPix™** as a Favourite	tap **Save as My Place**. The **NavPix™** is saved and the *NavPix Details* screen will display.
save the **NavPix™** as Home	tap **Save as Home**. The **NavPix™** is saved and the *NavPix Details* screen will display.

How do I add or edit a NavPix™ title?

A title can be added to your **NavPix™** or an existing title can be edited. The title can be a maximum of 34 characters.

1. From the *My Places* screen, tap a **NavPix™** you want to edit.
   The *Preview* screen will display.
2. Tap **Rename**.
   The *Keyboard* screen will display.
3. After you have edited the title, tap **OK**.
   The *NavPix Details* screen will display.

How do I delete NavPix™ from an Album?

1. From the *Album* screen, tap a **NavPix™**.
   The *NavPix Details* screen will display.
2. Tap .

How do I capture a location or a journey?

The capture functionality is not available on all models.

Your Mio has a capture feature which allows you to record GPS co-ordinates of a location, capture a location with a voice recording and capture a journey and save them so you can navigate back at a later time.

How do I capture the GPS co-ordinates of my location?

1. →
   The *Capture* screen will display.



2. Tap **Save**.
   You will hear a shutter sound to indicate that the GPS co-ordinates have been saved.
   The location is saved in My Places.

How do I capture a location with a voice recording?

This feature is not available on all models.

1. →
   The *Capture* screen will display.

2. Tap .
   The *Sound* screen will display.



3. Tap **Record** to start recording your voice.
   Tap **Stop** to stop the recording.

4. Tap **Save**.
   You will hear a shutter sound to indicate that the recording has been saved.
   The location is saved is saved in My Places.

How do I capture a journey?

To enable capturing of journeys, you must first enable **Capture Journey** from → **Route options**.

1. At the beginning of the journey you would like to record, tap **Clear**.
   All travel that you have made (i) since midnight, (ii) the previous time you tapped **Clear**, or (iii) last captured a journey, will be deleted.
2. Travel on your journey. Your Mio will keep a record of where you travel.
3. At the end of your journey, →
   The *Capture* screen will display.
4. Tap .
   The *Journey* screen will display.



5. Tap **Save**, then **Yes**.
   The journey is saved is saved in My Places.

How do I navigate to a location I have captured?

1. →
   The *My Places* screen will display.
2. Tap the captured destination you want to travel to.
   The *Preview* screen will display.
3. Tap .
   Your Mio will calculate the route from your current location. The *Map* screen will display.

How to view a journey I have captured?

1. →
   The *My Places* screen will display.
2. Tap the captured journey you want to view.
   The *Preview* screen will display.

How to share a journey I have captured?

You can share a saved journey via MioMore Desktop. See the *MioMore Desktop Manual* for more information on sharing a saved journey.

How do I create a trip with multiple stops?

You can use the *Planned Trips* screen to set multiple stops or waypoints for your trip. Your route will be calculated to go via each of these points in the specified order.

1. →
   The *Planned Trips* screen will display.



2. Tap **Create New Trip**.
   The *Edit* screen will display.



3. Tap the location name.
   The *Keyboard* screen will display.



4. After you have edited the name, tap **OK**.
   The *Edit* screen will display.

5. Tap **Add**.
   The *Add* screen will display.

6. Tap **Find a place**.
The *Search* screen will display.

You can also add waypoints using Home, My Places and Recent places.

7. Using the Find address wizard, search for a location.
The *Preview* screen will display.



8. Tap **Add as waypoint**.
The waypoint is automatically saved and the *Edit* screen will display.



9. Complete one or more of the following:

If you want to ...	Then ...
add another waypoint Waypoints added after a multi-stop trip has commenced will not be included in the current route.	▪ tap **Add**. The *Add* screen will display. ▪ return to step 4.

If you want to ...	Then ...
navigate to your selected destination	▪ tap . The *Map* screen will display the calculated route.
delete the trip	tap .
Have this trip demonstrated	tap **Simulate**. The *Map* screen will display your trip in demo mode. (See Shop Demo page 58.)

How do I delete a waypoint from my trip?

1. →
   The *Planned Trips* screen will display.
2. Tap the trip to edit.
3. Tap a waypoint on *Edit* screen.
   The *Preview* screen will display.



4. Tap **Delete**.
   The *Edit* screen will display.

How do I change the order of the waypoints?

1. →
   The *Planned Trips* screen will display.
2. Tap the trip to edit.
3. Tap a waypoint on *Edit* screen.
   The *Preview* screen will display.



4. Tap **Up** or **Down**.
   The *Edit* screen will display

How do I edit a planned trip title?

1. →
   The *Planned Trips* screen will display.
2. Tap the trip to edit.
3. Tap the current trip title.
   The *Keyboard* screen will display.
4. After you have edited the name, tap **OK**.
   The *Edit* screen will display.

How do I skip a waypoint during a multi-stop trip?

1. Tap the map screen.
2. Tap . When the caution dialog box displays, tap **Yes**.
   The next waypoint will be skipped and the route recalculated to the following waypoint.

What is Travel Book?

Travel Book is not available on all models and is only available in selected countries.

Travel Book is a collection of city guides that provide detailed Points of Interest maps for major cities in Europe. The city guides provide information on accommodation, dining, night life, business essentials, shopping, important tourist spots and practical information such as banks, medical centres, bus stations, etc.

Travel Book information is provided by third party. Mio does not guarantee the accuracy of the data contained within this database either expressed or implied.

How do I search for a POI in a city I am visiting using Travel Book?

1. Select your city from the available cities screen.
   The *City* screen will display.



2. Select a POI category from the list.
   The *POI category* screen will display.



3. Select a POI from the list.
   The *POI details* screen will display.

4. Complete the following:

If you want to ...	Then ...
calculate the route, open the *Map* screen and start navigating	▪ tap . The *Map* screen will display.
save the location as a favourite	▪ tap . The *Save* screen will display. ▪ tap **Save as My Place**.
explore the area near the location	▪ tap . The *Explore Map* screen will display. ▪ tap the undock button or tap the docked menu in Slide Touch™ mode to see the menu options. ▪ complete one of the following: o tap **Streets** to explore streets near your location o tap **Areas** to explore areas around your location o tap a POI category to explore POIs near your location
place a phone call to the POI	▪ tap . This feature is not available on all models.
read more information on the selected POI	▪ tap **More information**. The *More details* screen will display.

How do I add / remove city guides on my Mio?

You can add/remove city guides on your Mio via MioMore Desktop.

For more information on adding/removing city guides, refer to the *MioMore Desktop User Manual*.

How do I watch digital TV?

If an optional digital TV card is installed on your Mio, you can watch the local free-to-air digital TV programs.

WARNING DO NOT watch TV while driving. It may be illegal in your state or country for a display showing a video to be in view of the driver.

For information on installing the optional TV card and external antenna and using the remote control, refer to the *Hardware User Manual*.

Watching TV programs

1. When you use the TV feature for the first time, you will be prompted to scan the channels available in your area. Follow the prompts to finish the channel scan.
2. The screen will display the TV program when the signals are available. Tap anywhere on the screen to display on-screen controls.

3. Complete the following:

If you want to ...	Then ...
adjust the volume	tap and . You can also move the slider to the desired volume level.
change the channel	tap and . You can also move the slider to change the channel.
adjust the brightness	tap and . You can also move the slider to the desired brightness level.
view the information of the current program	tap .
change TV settings	tap .
exit the TV mode	tap .

Changing TV settings

Complete the following:

If you want to ...	Then ...
check the one-week program guide provided by the local digital TV program providers	tap **Electric Program Guide**. Select a date. The screen will show the program list of the selected channel. Tap a program to show the program information.
check the channel list	tap **Channel List**. Tap to switch to the selected channel.
show the subtitle (if supported by the local digital TV program providers)	tap **Subtitle**.
change the screen display	tap **Aspect Ratio** to change to full screen mode or 4:3 mode.
scan the channels available in your area	tap **Channel Scan**. Follow the prompts to finish the channel scan.

How do I play media?

Media is not available for all models and is only available in selected countries.

Media allows users to play stored media files installed on your Mio or on a memory card.



Playing audio files

Only mp3, wma, wav audio formats are supported for the audio feature.

If your files are on a memory card, insert the card into your Mio. You can play music files that are stored on your Mio or on a memory card by a random order, artist and albums.

How do I listen to a music file on my Mio?

There are several ways to play audio files on your Mio.

1. Complete one of the following:

If you want to ...	Then ...
play music files randomly	tap **Play Random**.
sort music files by an artist	tap **Artists** and select an artist from the *Artists* screen.
listen to music files in an album	tap **Albums** and select an album from the *Albums* screen.
play all music files	tap **Songs** and select a song to start with from the *Songs* screen.
play music files stores in a playlist	tap **Playlists** and select a playlist from the *Playlists* screen.

2. The *Songs* screen will display.



3. Complete one of the following:

If you want to ...	Then ...
play a music file	tap a music file from the list

If you want to ...	Then ...
listen to the previous music file	tap .
skip the current music file	tap .
pause the music file	tap . Tap to starting playing the audio file.
adjust the volume	tap .
mute the volume	tap .
unmute the volume	tap .
set play settings	in the **Play** section, tap **<** or **>** to see all options: ▪ select **Random** to play music files randomly. ▪ select **In Order** to play music files in order.
set repeat settings	in the **Repeat** section, tap **<** or **>** to see all options: ▪ select **Repeat All** to repeat all the music files. ▪ select **Repeat One** and the current music file will be repeated once. ▪ select **Off** to play the music files only once.

Playing video files

WARNING DO NOT view videos while driving. It may be illegal in your state or country for a display showing a video to be in view of the driver.

Only mp4, 3gp, m4v, asf, wmv and avi video formats are supported for the video feature.

If your files are on a memory card, insert the card into your Mio.

How do I view a video file on my Mio?

1. From the *Media* screen tap **Videos**.
   The *Videos* screen will display.



2. Complete one of the following:

If you want to ...	Then ...
play a video file	select a video file from the list
view the previous video file	tap . Tap and hold the icon for more than 1 second to rewind the video.
skip the current video file	tap . Tap and hold the icon for more than 1 second to fast-forward the video.

If you want to ...	Then ...
pause the video file	tap . Tap to start playing the video file.
adjust the volume	tap .
mute the volume	tap .
unmute the volume	tap .
View the video file on full screen	tap .
set play settings	in the **Play** section, tap **<** or **>** to see all options: ▪ select **Random** to play video files randomly. ▪ select **In order** to play video files in order.
set repeat settings	in the **Repeat** section, tap **<** or **>** to see all options: ▪ select **Repeat All** to repeat all video files. ▪ select **Repeat One** and the current video file will be repeated once. ▪ select **No Repeat** to play the video files only once.

How do I view a video file on full screen?

1. From the *Video* screen, select the video file that you would like to view at full screen.
   The video file will play at normal view size.
2. Tap the video.
   The video file will play at full screen.

- The icons will disappear after a few seconds; tap the screen to have them reappear.

3. Complete one of the following:

If you want to ...	Then ...
view the previous video file	tap . Tap and hold the icon for more than 1 second to rewind the video.
skip the current video file	tap . Tap and hold the icon for more than 1 second to fast-forward the video.
pause the video file	tap . Tap to start playing the video file.
adjust the volume	tap .
mute the volume	tap .
unmute the volume	tap .

If you want to ...	Then ...
return to the normal view	tap .
set play settings	in the **Play** section, tap **<** or **>** to see all options: ▪ select **Random** to play video files randomly. select **In order** to play video files in order.
set repeat settings	in the **Repeat** section, tap **<** or **>** to see all options: ▪ select **Repeat All** to repeat all video files. ▪ select **Repeat One** and the current video file will be repeated once. select **No Repeat** to play the video files only once.

How do I receive audio through my vehicle speakers?

FM transmitting is not available on all models and is only available in selected countries.

Your Mio can be set to transmit sound at a particular FM frequency which you can then receive through your vehicle radio. This means that you can hear map voice guidance, radio, mp3 files and video voice files clearly and loudly through your vehicle speakers.

How do I set the audio output channel of my Mio through my car's FM radio?

When you first access Audio output, the **Internal speaker** option is selected by default. If you select **FM transmitter** the most recently used FM frequency will be used.

1. From the *Settings* screen tap **Audio output**.
   The *Audio output* screen will display.
2. Select the **FM transmitter** option and then tap **Setup** to set the frequency.
   The *Set Frequency* screen will display.
3. Tap **OK** on the guidance message to continue.
4. Tap **Set Frequency** to set a new output frequency for your Mio.
   The *Set Frequency* screen will display.



   You need to tune the car radio to an empty channel. If driving long distances, you may need to retune to a new empty frequency.
5. Tap - or + to set a frequency.

   Tap and hold -/+ to decrease/increase by 1MHz. The fine-tuning frequency unit is 0.1MHz per unit.
6. Tap any of the save options.
   The FM screen will display with the saved frequency.

   You can only save four FM frequencies on your Mio. Tap **Apply Directly** to apply current frequency directly. **Apply Directly** option allows you to set the audio output channel automatically to FM (current frequency).
7. Tap and select the frequency you want to use.

To delete a saved frequency, you must set a new frequency and replace the frequency that you no longer require.

How do I receive current traffic information via TMC?

Traffic information is not available on all models and is only available in selected countries.

Your Mio can receive current traffic information for all main roads and motorways, enabling you to avoid potential delays on your route. Event messages and traffic icons will display as they occur. If an event message obscures your current location, the map will adjust to display both the message and your location.

How does my Mio receive traffic information?

Depending on your model, you may receive current traffic information on your Mio using the built-in TMC receiver or via the Mio traffic accessory kit. The traffic accessory kit may be sold separately.

The Traffic Message Channel (TMC) broadcasts real-time traffic and weather information via the FM Radio Data System (RDS). FM radio stations transmit TMC data on a cycle of several minutes, with hundreds of events able to be broadcast to TMC receivers.

You have to pay for TMC service on some models and in some countries.

Traffic status

Your current traffic status is indicated by the colour of the TMC icon.

To view your current traffic status, from the *Main Menu*, tap .

The following table describes the three traffic status icons:

Traffic Status	Description
	The TMC status is grey if traffic is currently inactive due to one of the following conditions: ▪ Your Mio or traffic accessory kit is connecting to the TMC service. ▪ Your Mio or traffic accessory kit cannot receive TMC data. This may be due to poor radio coverage in the local vicinity. ▪ You are in a country that is not supported by Mio traffic. ▪ Tap to display the *Traffic Overview* screen.
	The TMC status is orange if one of the following conditions apply: ▪ You have navigated into a country that is not supported by Mio Traffic, but there are still traffic events listed on the *Event List* screen. ▪ You have separated your Mio from the Mio traffic accessory kit, or the Mio traffic accessory kit is not receiving power but there are still traffic events listed on the *Event List* screen. ▪ Tap to display the *Traffic Overview* screen.
	The TMC status is green if your Mio or traffic accessory kit is active and receiving traffic events. ▪ Tap to display the *Traffic Overview* screen.

Your traffic status is displayed in more detail on the *Traffic System Status* screen.

How will I know when a Traffic Event occurs?

Incoming events are handled according to your Traffic preferences.

When travelling through an area in which you can receive traffic updates, your Mio will decode these events and display them on-screen. An icon will display at the event location on the map screens, and an audible warning is given if an event is on your route. Where an event spans a specific distance, the road will be highlighted and arrows will indicate the direction affected.



A message will display at the bottom of the screen with the road name, the section of road affected and the type of event that has occurred. The message remains on screen for 8 seconds and is added to the *Event List*.

Traffic Overview screen

Depending on your Mio model, traffic information may not be available, may require a subscription, or may require the Traffic Accessory Kit (may be sold separately).

The Traffic Overview screen displays a general overview of the traffic situation on your route, including all events in the immediate vicinity.



	Item	Description
❶	**State**	Indicates the number of events on your route.
❷	**Event icon**	Displays icon to indicate type of event.
❸	**Current position**	Your current position is marked with .
❹		Your current traffic status is indicated by the colour of the TMC icon.
❺		To zoom in or out, tap and hold or .

How do I view a list of all events on my route?

Your Mio creates a list of events as they are received, which is displayed on the *Event List* screen. This screen can only be viewed if the TMC icon is green or orange.

From the *Traffic Overview* screen, tap and undock the menu.



	Item	Description
❶		Tap to return to the previous screen.
❷	**Sort**	Display the *Set sort type* screen. Select your traffic event sorting option from the list.
❸	**Event description**	Displays details of the Event, including: ▪ Name of road and direction in which Event is taking place. ▪ Location of where Event begins and ends. ▪ **>** indicates an Event from a location, to a location. ▪ **<>** indicates an Event between locations. ▪ Type of Event.
❹	**Event icon**	Displays an icon to indicate type of event.

How do I view traffic details?

There are several ways to view details of an event received by your Mio.

Choose one of the following:

Traffic Status	Description
From any of the map screens used to view your route	▪ Tap the Event message when it appears on the map screen. The *Event Details* screen will display.
From the Traffic Overview screen	▪ Tap and undock the menu. The *Event List* screen will display. ▪ Select and tap the event you want to view. The *Event Details* screen will display. **OR** Tap and hold the traffic icon, which displays at the location of the event. The *Event Details* screen will display.



	Item	Description
❶		Tap to return to the previous screen.
❷	**Event icon and description**	Displays details of the Event, including: ▪ Name of road and direction in which Event is taking place. ▪ Location of where Event begins and ends. ▪ **>** indicates an Event from a location, to a location. ▪ **<>** indicates an Event between locations. Type of Event.
❸	**Detour information**	Displays details of detour recommendation, if any.
❹	**Avoid**	Tap to initiate a new route to avoid the event. Only available if a detour or re-route is available. The Unavoid Area button is displayed when a re-route has been calculated.

How do I know if a detour is recommended?

When a Traffic or Clearance event occurs on your route, a detour will often be recommended. The detour event message will display in the status bar on map screens.

Detours are only recommended for Traffic or Clearance Events on a calculated route.

How do I avoid an event on my route?

From the *Traffic Overview* screen, tap and undock the menu.

1. From the *Event List* screen, tap the event.
   The *Event Details* screen will display.
2. If a detour has been calculated to avoid an event on your route, Avoid is available; tap to accept the new route and avoid the event.
   The *Map* screen will display.

How do I cancel a detour around an event on my route?

If you have chosen to avoid an event and a new route has been calculated, you can cancel the detour around the event and return to your original route.

1. From the Event List screen, tap the Event you want to un-avoid.
   The Event Details screen will display.
2. Re-route information displays at the bottom of the screen.

- If a re-route has been calculated, Unavoid is available; tap to accept the new route.
  The Map screen will display.

Traffic messages

The *Event Details* screen displays detour status information.

Detour Not Available messages

If a detour is not available, one of the following messages will display:

Message	Description
This Event is not locatable This clearance is not locatable	A specific location for the Event cannot be identified.
This Event does not affect your route This clearance does not affect your route	The Event is not on the current leg of your journey, or is behind your current position.
You are avoiding this Event You have accepted this clearance	The Event is not on the current leg of your journey.
You are too distant to re-route You are too distant to accept this clearance	The Event is currently too distant to affect your journey.
Detour not found Clearance route not found	A detour / re-route could not be calculated.

Detour Recommended messages

If a detour is recommended, one of the following messages will display:

Message	Description
Finding detour.... Recalculating route.....	Your Mio is calculating a new route. During calculation, the % complete will display. Exiting this screen before the new route is calculated will cancel the operation.
Detour distance..... Clearance change	A detour has been calculated. The difference between the distance of your current route and the proposed route is displayed.

Traffic preferences

You can view your current traffic system status and change options by customising the traffic preferences.

TMC service

1. From the *Traffic Events* screen, tap **Traffic service**.
   The *Traffic service* screen will display.



The TMC service screen displays the frequency of the radio station currently used to receive traffic event information. A bar shows the strength of the traffic signal being received; the more green bars the stronger the signal.

2. Complete the following:

If you want to…	Then…
change your preferred radio station	select your preferred radio station from the list.

Traffic Event Notification

1. From the *Event List* screen tap **Preferences**.
   The *Preferences* screen will display.

2. Complete the following:

If you want to…	Then…
turn on/ off traffic event notification	select the **Notify me about nearby traffic events** button to receive traffic event notification. clear the **Notify me about nearby traffic events** button to turn off traffic event notification. Event icons will still display on the Map screen.
be notified about events that affect your current route	select the **Only notify me about events on my route** button.
be notified only when a detour is recommended	select the **Only notify me if a detour is recommended** button.

- Your preferences are automatically saved.

Select event sorting type

1. From the *Traffic events* screen tap the **Sort** field.
   The *Set sort type* screen will display.

2. Complete the following:

If you want to…	Then…
sort events by distance	select the **Distance** option.
sort events by road name	select the **Road name** option.

If you want to…	Then…
sort events by age	select the **Age** option.
view all traffic events	select the **Show all events** option.
view traffic events that appear only on your route	select the **Only show events** on my events option.

- Your preferences are automatically saved.

Walking mode

Walking mode is not available on all models.

Walking mode allows you to navigate to your destination using roads and paths appropriate for a pedestrian, including non-vehicle segments.

When in **Walking** mode, you will not be routed onto motorways and their associated slip roads. If your destination is more than 10 kilometres (6.3 miles) away, a warning message is displayed indicating that the route is a long way to walk.

Some aspects of walking mode are not available on all models, but the function itself is.

Navigation along paths and non-vehicle segments that require 2D city maps is not available on all models.

How can I set my navigation mode to walking?

1. Plan a route from the *Find* or *Explore* screen.
2. In the **Mode** section, tap **<** or **>** to select **Walking**.

   Your route will be calculated and the *Map* screen will display using the walking icon: .

What can I customise?

There are various customisation options available to enhance your navigation experience.

Volume



Complete the following:

If you want to ...	Then ...
increase or decrease the volume	▪ tap to move the **Volume** slider to the right to increase the volume. ▪ tap to move the **Volume** slider to the left to decrease the volume.

- Your preferences are automatically saved.

Safety options

You can enhance your navigation experience by modifying aspects of your route and route calculation.



Complete the following:

If you want to ...	Then ...
enable/disable a visual warning if the screen is accessed in a moving vehicle	tap **Warn me not to operate my Mio while driving**, to turn it **On** or **Off**.
enable/disable speed limit alerts, which warn you of the speed limit on any given road	tap **Speed limit warnings**, to turn it **On** or **Off**. When **Speed limit warnings** is set to **On**, the **Set manual speed alert** and **Speed alert type**, options will display.

- Your preferences are automatically saved.

Route options



Complete the following:

If you want to ...	Then ...
set route type options for your route	▪ Tap **Route type**. The *Route type* screen will display. ▪ Select your route type preference from the list. **Shortest** – The route with the shortest physical length **Easiest** – The simplest route with the least number of turns and favours motorways where appropriate **Economical** – The route with least number of stops, turns and urban areas which should save on fuel usage. **Fastest** – The route that should be the fastest when navigating Selecting **Shortest** route type over **Fastest** route type can cause a much longer journey time.
set types of road options for your route	▪ tap **Types of road**. The *Types of road* screen will display. ▪ select your road preference from the list. Avoiding ferry routes may prevent you from navigating between certain countries, even when a bridge or tunnel exists.
set your map screen preference	tap the **Map** option to select between a 3D or 2D view of the *Map* screen.
set the number of turns displayed on your turn list	▪ tap **Displayed turns**. The *Displayed turns* screen will display. ▪ select your turn preference from the list.
display junction views on your route	tap the **Junction views** options to turn it **On** or **Off**. This feature is not available on all models.
Set how you want to notified of safety cameras	▪ tap **My Places alerts**. The *My Places alerts* screen will display. ▪ select an option and then select your preference from the list.
record mileage for your route to generate expense reports	tap the **Mileage recorder** option to turn it **On** or **Off**. This feature is not available on all models. See the *MioMore Desktop Manual* for more information on exporting mileage reports.
record a GPS log of your trip	tap the **GPS logging** option to turn it **On** or **Off**.
record your journey	tap the **Capture Journey** option to turn it **On** or **Off**.

- Your preferences are automatically saved.

Map display



Complete the following:

If you want to ...	Then ...
enable/disable automatic zooming during navigation	tap the **Auto-zoom map when navigating** option to turn it **On** or **Off**. If selected, the Map screens will automatically zoom in or out, depending on your speed, to allow optimal viewing of your route.
display North at the top of the *2D Map* screen	tap the **Keep North at top of 2D map screen** option to turn it **On** or **Off**. If set to **Off**, the direction you are travelling in will display at the top of the *2D Map* screen.
display “no entry” icons on “no entry” roads on the *Map* screens	tap the **Show no-entry road signs** option to turn it **On** or **Off**. When turned on, the map display performance can slow down due to the number of no entry roads in some major cities.
Change the map colour scheme	tap the **Map scheme**, then select a colour scheme from the list.

- Your preferences are automatically saved.

Screen brightness



Complete the following:

If you want to ...	Then ...
change the screen brightness	▪ tap to move the **Screen Brightness** slider towards right to increase screen brightness. ▪ tap to move the **Screen Brightness** slider towards left to decrease screen brightness. **Warning:** Your Mio can heat up when the **Brightness** scale is set high, therefore, use lower brightness whenever acceptable.
set the screen contrast to automatically adjust	select the **Automatic day/night** option.
improve screen contrast in light or dark condition	select either **Day** or the **Night** option to manually adjust screen contrast.

- Your preferences are automatically saved.

Language

Complete the following:

If you want to ...	Then ...
change the on-screen language	tap your preferred language, then tap **Yes**. The voice scheme will also change to the default scheme for the selected language.

- Your preferences are automatically saved.

Voice

Complete the following:

If you want to ...	Then ...
change the voice scheme	select your preferred voice scheme from the list. Only voice schemes that are compatible with the chosen language are displayed.

- Your preferences are automatically saved.

Power management



The **Battery Status** bar shows the percentage of power left in the Mio battery. The words **External power** will display when the battery is charging from an external power source. Otherwise it will show **Internal battery** when not connected to an external power source.

To charge the battery, refer to the *Hardware User Manual*.

Units

Complete the following:

If you want to ...	Then ...
change the time format	tap **Time format** and then select your preferred time format from the *Units* screen.
change the distance units	tap **Distance Units** and then select your preferred distance unit type from the *Units* screen.
change the date format	tap **Date Format** and then select your preferred date format type from the *Units* screen.

- Your preferences are automatically saved.

Touch audio



The touch audio option allows you to hear a tone when you tap the touch screen.

Complete the following:

If you want to ...	Then ...
hear which letter you have tapped when you tap the touch screen	tap the **Audio** option to turn it **On** or **Off**.
hear a tone when you use the on-screen keyboard for text input	tap the **Speak keyboard letters** option to turn it **On** or **Off**.

- Your preferences are automatically saved.

List scrolling



Complete the following:

If you want to ...	Then ...
enable the Slide Touch™ interface and not use arrows to navigate on a screen	tap the **List Scrolling** option to select **Slide Touch**.
disable the Slide Touch™ interface and use the scroll tabs	tap **List scrolling** option to select **Buttons**.

- Your preferences are automatically saved.

Audio output

This feature is not available on all models.

Audio output allows you to change the audio output of your Mio.



Complete the following:

If you want to ...	Then ...
Receive audio output through your Mio	Select the **Internal Speaker** option.
Receive audio output through the FM radio in your car	Select **FM transmitter** and then select your FM frequency. For more information, see “How do I receive audio through my vehicle speakers?” on page 53.

- Your preferences are automatically saved.

Delete saved information



Complete the following:

If you want to ...	Then ...
delete My Places	tap **Delete My Places**.
delete recent locations	tap **Delete recent locations**.
clear all settings; for example, for use in a rental car	complete all of the above.

- When the warning dialog box displays, tap **Yes**.

Reset GPS

Occasionally, the GPS fix may need to be reset. This may occur if the receiver has been transported a long distance since last being used; for example, to a different country, and is still trying to establish the previous position.

Complete the following:

If you want to ...	Then ...
reset the GPS	▪ tap **Reset GPS**. ▪ When the warning dialog box displays, tap **Yes**.

Restore factory defaults

The restore factory defaults option allows you to restore default factory settings.

Complete the following:

If you want to ...	Then ...
restore factory default settings	tap **Restore Factory Defaults**. Your Mio will restart. The **Restore Factory Defaults** option does not delete recent locations or saved My Places destinations.

- Your preferences are automatically saved.

Shop demo

Complete the following:

If you want to ...	Then ...
enable a shop demonstration of Mio Spirit to be played	tap **Shop demo**. Tap **Yes** and select a demonstration country. Tap **OK**. Your Mio will restart. When your Mio is in Shop demo mode, you will see the navigation demonstration of the pre-defined route without having to set a destination. You cannot operate your Mio properly in Shop demo mode.
stop a shop demonstration of Mio Spirit in playback	tap **Shop demo**. Tap **Yes**, then **OK**. Your Mio will restart.

Screen saver

Complete the following:

If you want to ...	Then ...
enable the screen saver feature on your Mio	tap **Screen saver**. When your **Mio** is idle for 10/30/60 minutes, the screen saver will display. The screen saver will only display if your Mio is connected to a power supply. To stop the screensaver playing, simply tap the screen.
Disable the screen saver feature on your Mio	tap **Screen saver**. Tap **Off**.

- Your preferences are automatically saved.

About

Tap **About** to display copyright and trademark information.

Point of Interest categories

Icon	Description	Icon	Description
	Airport		Amusement park
	Art centre		ATM/Cash dispenser
	Bank		Bar/Pub
	Beach		Breakdown service/Car repair facility
	Bowling centre		Business facility or company
	Business office		Bus station
	Camping ground		Car dealer/Automobile dealer
	Casino		Cemetery
	Church		Cinema
	City hall		City, town or village
	Coffee shop		College/University
	Community centre		Commuter railway station
	Courthouse		Dentist
	Doctor		Embassy
	Exhibition centre		Ferry terminal
	Fire Brigade		Golf course
	Government office		Grocery store
	Guest house		Higher education
	Hospital/Polyclinic		Hotel
	Ice skating		Important tourist attraction
	Information/Tourist information office		Library
	Marina/Yacht basin		Medical
	Monument		Motorcycle dealer

Icon	Description	Icon	Description
	Motoring organisation office		Mountain pass
	Museum		Music centre
	Natural attraction		Nightlife
	Park and ride		Parking
	Parking garage		Park/Recreation area
	Performance art/Theater		Petrol station
	Pharmacy		Place of worship
	Police station		Post office
	Public restroom/Toilet facilities		Public sport airport
	Railway crossing		Rental car agency
	Rest area		Restaurant
	Road accident black spot		Scenic/Panoramic views
	School		School zone
	Shop		Shopping
	Ski resort/Ski lift station		Speed check
	Sport centre		Sports hall
	Sports complex		Stadium
	Tennis court		Travel agency
	Transport ferry		Veterinarian
	Winery		Zoo

Branded Points of Interest

Branded Points of Interest are available on some maps. These include well known restaurants, accommodation providers, tourist attractions, Petrol stations, etc. The icon will usually display the company logo.

Point of Interest categories by subscription

Icon	Description
	Safety Cameras
	Safety Camera (Mobile)
	Safety Camera (Average)
	Red Light Camera

My Places categories

Icon	Description
	Album
	Home
	Picture
	Saved locations
	Captured locations
	Captured journey
	Captured sound recording

Traffic and other TMC Events

Each TMC Event is sorted in to one of nine categories. When an Event is received, one of the following icons will display:

Event	Avoided Event	Message Type	Event Description
		Danger	There is a dangerous situation on the route; for example, people are on the road.
		Traffic	Any event that will cause a delay on a route.
		Weather	Weather conditions are adversely affecting a route; for example, there is ice on the road.
		Warnings	There is a situation of which you should be aware on the route, but it is not serious enough to be considered a dangerous situation; for example, a minor accident has taken place.
		Forecast	An event is expected to occur on a route.
		Restrictions	There is a restricted flow of traffic on a route; for example, a lane has been closed on a motorway.
		Clearance	A traffic event that has now been cleared.
		Information	All other events.
		Roadworks	Roadworks are taking place on a route.

If a *Traffic* or *Clearance* event has a recommended detour, the following icons will display:

Event	Avoided Event	Message Type	Event Description
		Traffic Detour	A *Traffic* Event, for which a detour is recommended.
		Clearance Re-route	A Clearance Event, for which a re-route is recommended.

Avoided Event icons will only display on the *Map* screen, at the event location.

Appendices

For more information

User Manuals

The latest User Manuals can be downloaded from our website: www.mio.com

Register with MioClub

To report a faulty product or speak to a member of our Technical Support team, register your Mio on MioClub to obtain the Technical Support phone numbers for your region.

Speed Limit

Mio products are designed to be used as an aid to safer driving. Mio does not condone speeding or any other failure to comply with your local traffic laws. It is your responsibility to drive within the posted speed limit at all times and to drive in a careful manner. Mio accepts NO liability whatsoever for you receiving any speeding fines or points on your license through using this device. Mio does not guarantee the accuracy of the data contained within this database either expressed or implied. In the event you receive a fine or any other penalty for speeding or contravention of any traffic law, or are involved in an accident, Mio is not responsible for any damages of any type. In some countries the data information regarding speed limits may conflict with local law and/or regulations. It is your responsibility to make sure that your use of the data is in compliance with local laws and/or regulations. Usage is at your own risk.

Safety Camera POIs

Mio products are designed to be used as an aid to safer driving. You can receive messages to alert you to locations of safety cameras, which will enable you to monitor your speed through these areas. Mio does not warrant that all types and locations of safety camera data are available, as cameras may be removed, relocated or new cameras installed. Mio does not condone speeding or any other failure to comply with your local traffic laws. It is your responsibility to drive within the posted speed limit at all times and to drive in a careful manner. Mio accepts NO liability whatsoever for you receiving any speeding fines or points on your license through using this device. Mio does not guarantee the accuracy of the data contained within this database either expressed or implied. In the event you receive a fine or any other penalty for speeding or contravention of any traffic law, or are involved in an accident, Mio is not responsible for any damages of any type. In some countries the data information regarding safety or speed cameras may conflict with local law and/or regulations. It is your responsibility to make sure that your use of the data is in compliance with local laws and/or regulations. Usage is at your own risk.

FM Transmitter

Products with FM Transmitter feature may be operated in the following countries: Andorra, Austria, Belgium, Denmark, Finland, Germany, Ireland, Liechtenstein, Luxembourg, Monaco, Netherlands, Norway, Portugal, San Marino, Spain, Sweden, Switzerland, Great Britain and Vatican City.

The FM Transmitter feature is not allowed to be used by law in France, Andorra, San Marino, and Vatican City. Please turn of the FM Transmitter in those areas.

Disclaimer

Mio operates a policy of ongoing development. Mio reserves the right to make changes and improvements to any of the products described in this document without prior notice. Mio does not warrant that this document is error-free. The screenshots and other presentations shown in this manual may differ from the actual screens and presentations generated by the actual product. All such differences are minor and the actual product will deliver the described functionality as presented in this User Manual in all material respects.

Copyright

© 2009 MiTAC International Corporation. Mio is a registered trademark of MiTAC International Corporation and is used under licence by Mio Technology Ltd. All rights reserved.

The software contains proprietary information of MiTAC International Corporation; it is provided under a licence agreement containing restrictions on use and disclosure and is also protected by copyright law. Reverse engineering of the software is prohibited.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Mio.

Back-On-Track, Drive-Away, MioMore Desktop, Mio Spirit, **NavPix**, Slide Touch and Turn-by-Turn are either registered trademarks or trademarks of MiTAC International Corporation and are used under licence by Mio Technology Ltd. All rights reserved.

microSD and the microSD logo are trademarks of SD Card Association.

All other trademarks and registrations are the property of their respective owners.

Revision: R02
(6/2009)